XFIRE-001 STORAGE SOLUTION

Storage Kit for Crossfire™ Core Boxes (Dragonfire™, Prime Runner Crossfire™)
Complete insert kit providing storage for cards, tokens, character sheets, and stickers

Construction Tips

1) Each piece should be removed from the frames with gentle pressure back and forth. You should not need a knife to cut pieces free.

2) Our inserts are designed to be glued together. We use Sobo craft glue, but any glue that is tacky and dries clear will work fine. Tacky glue assists with building as it holds better during construction. You can use painter's/masking tape for some joins, but glue is always best.

3) Ensure you cleanup excess glue as you build. This is especially important in card lanes where dividers will be used or in spaces where a tray will be stored.

4) Check the build diagrams included in the package for reference, including all parts, as well as build tips specific to this insert.

5) **Always dry fit pieces first** to ensure a good fit and to better understand how the kit goes together.

6) Allow your finished insert to dry overnight.

7) You can optionally sand and even stain your insert.

8) Don't hesitate to reach out to us if you have questions!

Visit go7gaming.com for a large selection of storage solutions. Follow us on Twitter: @go7gaming and Facebook: go7gaming

GO 7 GAMING
Made in the USA

NOT A CHILDREN'S TOY
AGE 14+

6 80577 93153 4

Build Instructions

Building the Token Tray – DF mode

If you wish to use this storage solution with Dragonfire™, construct the tray in DF mode using these instructions. Note that only one complete token tray can be constructed as they each share the base, lid, and end walls.

1) Place base (**A**) down on your workspace in the orientation noted.
2) Next, apply glue to the bottom of inner walls (**B, C**) and connect to base (**A**).
3) Next, place glue on both side tabs of inner walls (**B, C**) and the bottom of outer wall (**D**) and connect. Repeat on the other side.
4) Next, apply glue to the bottom and side tabs of end wall (**E**) and connect. Repeat on the other side.
5) Finally, place glue on the side tabs of the four (4) inner walls (**F**) and connect to the tray.

6) Once your tray has had a few minutes to dry, carefully place lid (**Z**) on the tray and allow the tray to dry with the lid on it. This will ensure a perfect fit for your token tray once dry.

Building the Token Tray – SCPRE Mode

If you wish to use this storage solution with Shadowrun Crossfire Prime Runner Edition™, construct the tray in SCPRE mode using these instructions. Note that only one complete token tray can be constructed as they each share the base, lid, and end walls.

1) Place base (**A**) down on your workspace in the orientation noted.
2) Next, apply glue to the bottom of inner walls (**B, L**) and connect to base (**A**). Take care to ensure inner wall (**L**) is oriented properly.
3) Next, place glue on both side tabs of inner walls (**B, L**) and the bottom of outer wall (**M**) and connect. Repeat on the other side.
4) Next, apply glue to the bottom and side tabs of end wall (**E**) and connect. Repeat on the other side.
5) Finally, place glue on the side tabs of the three (3) inner walls (**O**) and connect to the tray.

6) Once your tray has had a few minutes to dry, carefully place lid (**Z**) on the tray and allow the tray to dry with the lid on it. This will ensure a perfect fit for your token tray once dry.

Build Instructions

Building the Main Insert

The main insert provides storage for your cards, sticker/ campaign sheets, anf character shields. It also provides a storage area for your token tray.

Note: as you build this insert, please note the orientation of the pieces. They have cuts in the upper area of the rails that should align across the insert, so that the game manual can be stored on top.

Also, blue painters tape is a great aid for holding corners in place while the glue dries.

1) Place glue on the side tabs of inner splitter wall (**A**) and connect to inner walls (**B**).
2) Next, apply glue to the right side tabs of both inner walls (**B**) and connect to rear inner wall (**C**).
3) Next, apply glue to the side tabs of rear inner wall (**C**) and connect to both inner divider walls (**D**).
4) Next, apply glue to the right side tabs of inner divider walls (**D**) and connect to outer wall (**E**).

Building the Main Insert (cont'd)

5) Next, apply glue to the left side tabs of inner walls (**B, B, D, D**) and and connect outer wall (**F**).
6) Finally, apply glue to the side tabs of outer wall (**G**) and connect. Repeat on the other side.

7) After your insert has had 5 minutes to dry, place the two long divider walls (not shown) into your insert, along with several small dividers in both card lanes, to ensure your insert dries providing a perfect fit.

8) Also, carefully slide your token tray with lid attached into its slot in the insert to ensure there is no glue that would interfere with insertion, once dried.   Once placed, slide it out and back in once or twice before leaving it in place while the main insert dries.

Congratulations! You have completed the construction of your new storage solution.