

# EXTRA TRAY KIT FOR MD-001 SOLUTION

Model MD-002 Tray Kit for use with MD-001 Storage Solution

This kit contains two (2) tray kits for use with the MD-001 storage solution



## Construction Tips

- 1) Each piece should be removed from the frames with gentle pressure back and forth. You should not need a knife to cut pieces free.
- 2) Our inserts are designed to be glued together. We use Sobo craft glue, but any glue that is tacky and dries clear will work fine. Tacky glue assists with building as it holds better during construction. You can use painter's/masking tape for some joins, but glue is always best.
- 3) Keep some paper towels handy for cleanup during build.
- 4) Ensure you cleanup excess glue as you build. This is especially important in card lanes where dividers will be used or in spaces where a tray will be stored.
- 5) Check the build diagram included in the package for reference, including all parts, as well as build tips specific to this insert.
- 6) Always dry fit pieces first to ensure a good fit and to better understand how the kit goes together.
- 7) Allow your finished insert to dry overnight.
- 8) You can optionally sand and even stain your insert.
- 9) Don't hesitate to reach out to us if you have questions!

Visit [go7gaming.com](http://go7gaming.com) for a large selection of storage solutions. Follow us on Twitter: [@go7gaming](https://twitter.com/go7gaming) and Facebook: [go7gaming](https://www.facebook.com/go7gaming)




Made in the USA


NOT A CHILDREN'S TOY  
**AGE 14+**



# Kit Plates



## 3D Model



## Build Instructions

The two trays in this kit are used in conjunction with the MD-001 storage solution for Massive Darkness. These trays can be placed in the area left open in the MD-001 to store the class pads and hero dashboards. If you use these trays you will need to store your class pads and dashboards elsewhere. We recommend you use one of the small add-on boxes. They are the perfect size!

These trays provide single and shared mini storage for the MD-001 storage solution. Always dry fit your build first and cleanup all excess glue as you build to ensure a clean fit and finish for dividers and such.

- 1) Lay base (A) down on your workspace.
- 2) Next, place glue on the bottom and end tabs of end wall (C) and connect to base (A).
- 3) Next, place glue on the bottom of side wall (B) and connect.
- 4) Next, place glue on the bottom and end tabs of end wall (C) and connect.
- 5) Finally, place glue on the bottom of side wall (B) and connect.
- 6) You can seat the inner walls (D), but don't glue until you determine what you want to store in them.
- 7) You can seat a few dividers (E), but don't glue them until you determine what you want to store in them.